LARGE SLOT **TOASTER**

GB IE CY **LARGE SLOT TOASTER**
Operating instructions

KOMPERNASS GMBH · BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: KH1553-07/08-V2

1
2
3
4
5
6
7
8
9
bifinett

CONTENT PAGE

Intended use	2
Technical data	2
Items supplied	2
Important safety instructions	2
Appliance description	3
Tips on usage	3
Before taking into use	3
Adjusting the level of browning (Toasting time)	3
Toasting	3
Interrupting the toasting process	4
Warming function	4
Thaw function	4
Crumb tray	4
Bread roll holder	4
Cleaning and care	5
Disposal	5
Warranty and Service	5
Importer	6

Read these operating instructions carefully before using the appliance for the first time and preserve this maual for later reference. Pass this manual on to whoever might acquire the appliance at a future date.

LARGE SLOT TOASTER KH 1553

Intended use

This appliance is intended for the toasting of slices of bread, rolls and waffles in domestic environments. It is not intended for use with other foodstuffs, other materials or for use in commercial or industrial environments. All other usages or modifications are regarded as being contrary to the operating instructions and carry with them a real risk of serious accidents.

Technical data

Power supply: 230V ~ 50 Hz
Nominal power: 850 W

Items supplied

Broad-Slot Toaster
Bread roll holder
Operating Instructions

Important safety instructions

⚠ *To avoid potentially fatal electric shocks:*

- NEVER insert cutlery or other metallic objects into the toaster slots.
- Ensure that the appliance never comes into contact with water when the power plug is inserted into a wall socket, especially if it is being used in a kitchen and close to the sink.
- Ensure that the power cable never gets wet or moist when the appliance is in use. Lay the cord such that it does not get clamped or otherwise damaged.
- Arrange for defective power plugs and/or cables to be replaced at once by qualified technicians or our Customer Service Department.
- After use, always remove the power plug from the wall socket, this prevents the unintentional switching on of the appliance.

⚠ *To avoid the risks of fire or injury:*

- The appliance can become hot when it is in use. Therefore, only touch the operating elements.
- Bakery products can burn! You should therefore NEVER locate the appliance close to or underneath inflammable objects, especially not under curtains or suspended cupboards.
- The appliance may not be used in close vicinity to flammable material.
- NEVER cover the toaster when it is in use.
- This appliance is not intended for use by individuals (including children) with restricted physical, physiological or intellectual abilities or deficiences in experience and/or knowledge unless they are supervised by a person responsible for their safety or receive from this person instruction in how the appliance is to be used.
- Children should be supervised to ensure that they do not play with the appliance.
- Operate the appliance only on a stable, non-slippery and level surface.
- Do not use an external timing switch or a separate remote control system to operate the appliance.
- Unwind the power cable completely from the cable winder before using the appliance.

Appliance description

❶ Bread roll holder
❷ Toasting slot
❸ Operating button
❹ Browning regulator (for infinitely adjustable toasting time electronics)
❺ Stop button for interrupting the toasting process
❻ Button for the warming function
❼ Button for thaw function
❽ Cable winder
❾ Crumb drawer

Tips on usage

- Toast mixed-flour breads at higher browning levels than white bread. Matured, dry bread browns faster than fresh bread.
- In the event of a malfunction and when cleaning the appliance, always remove the plug from the wall power socket.
- Loosen jammed slices of bread with a blunt wooden object (e.g. a wooden spatula or spoon). Do NOT touch the heater elements.
- Differences in bread sorts, moisture and the thickness of individual slices influence the browning of the toast. Therefore the bread for toasting should be kept in sealed packaging until required.

Before taking into use

Completely unwind the power cable from the cable winder ❽.

Then heat the appliance up at least five times at the maximum setting without the insertion of bread slices. For details on cleaning the appliance read the section »Cleaning and Care«.

Please take note:
The operating button ❸ only engages when the power cable is connected to a power socket. With the first usage a slight smell can arise (minimal smoke development is also possible). This is normal and dissipates after a short time. Please provide for adequate ventilation. Open a window, for example.

Adjusting the level of browning (Toasting time)

The desired level of browning, from "light" (1) to "dark" (7) can be adjusted infinitely with the browning regulator ❹ of the toasting time electronics.

ⓘ Take note that, subject to the demand made on the toaster, the level of browning can vary somewhat with an unvarying adjustment of the browning regulator ❹! The less the number of slices inserted, the higher is the browning level. Thus, if you are not intending to toast many slices, always adjust the browning regulator ❹ a little lower.

Toasting

⚠ ***Attention:***
NEVER cover the toaster slots ❷ when operating the toaster! There is a risk of fire! The appliance could be irreparably damaged!

- After setting the desired browning level, insert the bread into the toaster slots ❷.
- Press the operating button ❸ downwards. The control lamp integrated into the stop button ❺ glows.
- The automatic bread centering device centres the inserted bread in the toaster slots ❷.
- When the desired level of browning has been reached the toaster switches itself off automatically and the slices are ejected to the top.

- This appliance has a lifting function, which makes it easier and safer for you to take the hot slices of toast from the toaster slots ❷. For this, slide the operator button ❸ upwards.

Interrupting the toasting process

If you wish to interrupt the toasting process, press the STOP button ❺. The toaster switches itself off.

Warming function

The warming function ❻ makes it possible for you to warm bread without browning it. For example, for toast that has gone cold. The bread is only briefly warmed.

- Insert the bread and press the operator button ❸ down.
- Activate the button for the warming function ❻. The control lamp integrated into the button for the warming function ❻ glows.
- The toaster switches itself off automatically, the control lamp extinguishes and the bread slices are ejected.

Thaw function

Through activation of the thaw function ❼ frozen bread can also be thawed. The toaster slowly warms the bread without browning it.

- Insert the bread and press the operator button ❸ down.
- Activate the button for the thaw function ❼. The control lamp integrated into the button for the thawing function ❼ glows.
- The toaster switches itself off automatically, the control lamp extinguishes and the bread slices are ejected.

ⓘ Dependent on the setting of the browning level, the bread is either thawed or browned.

Crumb tray

When toasting, crumbs that fall from the bread are collected in the crumb tray ❾. To empty it, simply pull the crumb tray ❾ out to the side.

Bread roll holder

- NEVER lay bread rolls directly onto the toaster, ALWAYS use the bread roll holder ❶.
- Place the bread roll holder ❶ over the toasting slots ❷ and ensure that it is sitting firmly.
- Set the browning regulator ❹ to at least level 3. Dependant on the desired level of browning or the type of bakery product, the adjustment of the browning regulator ❹ can vary.
- Place the bread rolls onto the holder and start the toasting procedure.

ⓘ Place the rolls onto the bread roll holder ❶ so that they cannot fall through the holder.

⚠ ***Attention!***
After toasting, the rolls will be very hot. Risk of Burns!

- As soon as the toaster switches itself off, turn the rolls to toast the other side of them then switch the toaster back on.

⚠ *Attention!*

The bread roll holder ❶ and the metallic upper surfaces of the toaster will become very hot. Do not touch them during the toasting procedure or shortly thereafter. Risk of Burns!

- When you no longer require the bread roll holder ❶, first allow it to cool down. Then remove it from the toaster.

Cleaning and care

⚠ *Danger!*

Before cleaning, remove the power plug from the wall socket and allow the toaster to cool down. Risk of injury!

NEVER submerse the appliance in water or other liquids. The appliance could become damaged!

⚠ *Warning about damage to the appliance!*

Do not use aggressive or abrasive cleaning agents. These can damage the upper surfaces of the appliance.

- Clean the appliance housing only with a dry or lightly moistened cloth.
- If necessary, use a stainless steel cleaner.
- To avoid the risk of fire, empty the crumb tray ❾ at regular intervals.
- If you do not intend to use the toaster for an extended period, wrap the power cable around the cable winder. ❽.

Disposal

Do not dispose of the appliance in your normal domestic waste. This product is subject to the provisions of European Directive 2002/96/EC.

Dispose of the appliance through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations.
In case of doubt, please contact your waste disposal centre.

Dispose of all packaging materials in an environmentally friendly manner.

Warranty and Service

With this appliance you receive a warranty of 3 years from the date of purchase. The appliance has been manufactured with care and has been conscientiously examined and tested before delivery. Please retain your receipt as proof of purchase. In the case of a warranty claim, please make contact by telephone with our service department. Only in this way can a post-free despatch for your goods be assured.
The warranty covers only claims for material and maufacturing defects, not for wearing parts or for damage to fragile components, e.g. buttons or batteries. The appliance is intended solely for private domestic use, not for commercial applications.
If this product has been subjected to improper or inappropriate handling, abuse, or interventions not carried out by one of our authorised sales and service outlets, the warranty will be considered void. This warranty does not affect your statutory rights.

(GB) **DES Ltd**
Units 14-15
Bilston Industrial Estate
Oxford Street
Bilston
WV14 7EG
Tel.: 0870/787-6177
Fax: 0870/787-6168
e-mail: support.uk@kompernass.com

(IE) **Irish Connection**
Harbour view
Howth
Co. Dublin
Tel: 00353 (0) 87 99 62 077
Fax: 00353 18398056
e-mail: support.ie@kompernass.com

Importer

KOMPERNASS GMBH
BURGSTRASSE 21
D-44867 BOCHUM, GERMANY

www.kompernass.com